

* CURB AGGREGATE COURSE-WHERE THE ROADWAY PAVEMENT HAS AGGREGATE BASE, MATCH THE BOTTOM OF THE CURB AGGREGATE COURSE TO THE TOP OF SUBGRADE. ENSURE ROADWAY SUB BASE MEETS UNDERDRAIN AGGREGATE.

IF THE TOP OF THE SUBGRADE IS BELOW THE BOTTOM OF THE CURB, THE UNDERDRAIN SHALL BE ADJUSTED TO KEEP THE TOP OF THE UNDERDRAIN AT LEAST 8" BELOW THE TOP OF THE SUBGRADE; AGGREGATE DEPTH BETWEEN BOTTOM OF CURB AND TOP OF UNDERDRAIN MAY VARY IF THIS OCCURS.

SUBGRADE COMPACTION SHALL BE COMPLETED BEFORE UNDERDRAIN INSTALLATION.

WHEN CURB, BACK OF WALK, IS REQUIRED BEHIND SIDEWALK OR CURB RAMPS SEE STD. DWG. 2001

WHEN A CURB AND GUTTER INLET IS INSTALLED, THE TOP OF THE CASTING SHALL BE THE SAME AS THE TOP OF CURB ELEVATION. THE EDGE OF PAVEMENT ELEVATION SHALL BE 3/8" HIGHER THAN THE GRATE WHEREVER THEY MEET.

FOR REPLACEMENT WORK, THE CURB SHALL BE REMOVED AT AN EXISTING JOINT OR NO CLOSER THAN 5 FEET FROM AN EXISTING JOINT.

1/2" EXPANSION MATERIAL WILL BE INSTALLED BEHIND THE CURB WHEN A CONCRETE WALK, DRIVE, OR OTHER CONCRETE ITEM IS ADJOINING IT.

UNDERDRAIN IS NOT REQUIRED WHEN CURB IS ALONG CONCRETE MEDIAN OR BACK OF WALK OR RAMP.

