



LEVEL & SLOPE THE SUBGRADE AS SHOWN. COMPACT THE SUBGRADE AROUND THE FOUNDATION. THOROUGHLY CLEAN THE CONCRETE FOUNDATION SURFACE SO THE WALK CONCRETE WILL BOND.

LEAVE THE FOUNDATION CONCRETE DOWN 8" TO 9". POUR THE WALK CONCRETE OVER THE FOUNDATION.

NOTE:

WHEN POURING WALK, EMBED 1/2" THICK EXPANSION JOINT FILLER (CMSC 608.03C AND 705.03). FORM A 3'x3' SQUARE (STRAIN POLE AND MAST ARM POLE FOUNDATION) OR 2'x2' SQUARE (PEDESTAL POLE FOUNDATION) AND CENTER THE JOINT FILLER AROUND THE FOUNDATION AS DIRECTED BY THE ENGINEER. ORIENT THE EXPANSION JOINTS PARALLEL TO OTHER GEOMETRIC LINES.

POLE FOUNDATION IN SIDEWALK AREA

CITY OF COLUMBUS, OHIO
DEPARTMENT OF PUBLIC SERVICE
DIVISION OF DESIGN AND CONSTRUCTION

Hassan Zahran

CITY ENGINEER

STD DWG
4161

5/01/2014

SHT 1 OF 2

