



NOTES

- OUTLET AND/OR OVERFLOW CONTROLS ARE GENERALLY ONLY NEEDED AT SAGS OR IN FACILITIES THAT REQUIRE A MINIMUM DRAW DOWN TIME. IF CONTROL IS NOT NECESSARY, A CLEAN OUT SHALL BE INSTALLED.
- PRECAST WALLS SHALL BE IN ACCORDANCE WITH ASTM C-913 UNLESS DETAILED DESIGNS ARE PROVIDED WITHIN THE CONSTRUCTION DOCUMENTS.
- SMOOTH DRAINAGE NOTCHES TO BE INSTALLED ON THE REAR WALL AT BASIN CORNERS AND ON 20' SPACING.

CITY OF COLUMBUS, OHIO DEPARTMENT OF PUBLIC UTILITIES DIVISION OF SEWERAGE & DRAINAGE

APPROVED:

SSES MANAGER

8/26/22 DATE

BUMP OUT/BUMP IN WITH REAR WALL NOT CONTINUOUS WITH CURB STANDARD DRAWING AA-S183

REVISED 8/19/22

PAGE